


# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model		Mounting Hardware Kit
<b>Airstream</b>	Land Yacht		Freightliner	XC	41-230	F-143K2
	Land Yacht		Workhorse	P30 / P32	31-140	P-30KB14
	Sky Deck		Freightliner	XC	41-230	F-143K2
<b>Alfa Leisure</b>	Alpha Gold (Independent Front Suspension) Neway 114	2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Alpha Gold (Independent Front Suspension) ZF Model	2004	Freightliner	XC - IFS		N/A
	See Ya	2002 - 2008	Freightliner	XC	41-230	F-143K2
<b>American Coach</b>	Allegiance 40	2009	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Allegiance 42	2009	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Eagle IFS	2007	Spartan	IFS	26-230	S-1460K4
	Eagle 40/45	2008 - 2012	Spartan	Liberty Tuthill 1660	41-230	S-1460K4
	Heritage 45BT	2011 - 2012	Spartan	K3 Tuthill 1660	41-230	S-1460K4
	Heritage 45		Spartan	K3 Dana IFS 84		N/A
	Heritage 45	2008 - 2012	Spartan	K3 Tuthill 1660	41-230	S-1460K4
	Revolution	2011 - 2012	Spartan	MMGT I-beam	41-230	S-124K3
	Tradition	2008 - 2012	Spartan	Liberty Tuthill 1460	41-230	S-1460K4
<b>Barth</b>	Regency MCC				41-230	B-145K
	Regency With Generator In Front				41-230	B-319K2
<b>Beaver</b>	Contessa 38/40	Through 2009	Roadmaster	RR8S	41-230	G-002K4
	Contessa 42	Through 2009	Roadmaster	RR10S	41-230	G-002K4
	Marquis	Through 2009	Roadmaster	S-SERIES	41-230	G-002K4
	Monterey	Through 2009	Roadmaster	M-SERIES	41-230	G-002K4
	Patriot	Through 2006	Roadmaster	S-SERIES	41-230	G-002K4
	Patriot Thunder	Through 2009	Roadmaster	S-SERIES	41-230	G-002K4
	Santium	Through 2005	Roadmaster	RR8R	41-230	G-002K4
<b>Bluebird</b>		1994 & Prior			41-230	G-002K2
	Independent Front Suspension ( I.F.S )	2004 & After				N/A
	Wander Lodge LX & LXI (With 16,000 Lb Axle)	2001 - 2004			41-230	B-159K3
	Wanderlodge LX & LXI (With 1 3/4" Tie Rod)	1995 - 1998			41-230	B-165K3
	Wanderlodge LX & LXI (With 2 1/4" Tie Rod)	1995 - 2000			41-230	B-165K5
<b>Borne Free</b>	24 RB	2008	Ford	E-450	31-140	E-340K13
<b>Chevrolet</b>	1500, 2500 & 3500 Series Van & Class C	1996 - 2001			31-140	C-323K12
	3500/4500 Cutaway Express (Van style front end)	2002 - 2015			31-140	C-354K14
	Astro Van	1992			31-140	C-336K11
	C-30 Stabilizer (Sway) Bar (Also Dually)	1979 - 1988			31-140	C-347K13
	C-30 W/O Stabilizer (Sway) Bar (Also Dually)	1979 - 1988			31-140	C-30KA13
<b>Chevrolet</b>	C-4500 With 1-3/4 Tie Rod	2004			41-180	S-124K3

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	<b>SAFE T PLUS</b>	Mounting Hardware Kit
	C-4500 With 1-5/8 Tie Rod	2006			41-180	G-002K2.5
	C-5500 (Some may require fab new U-bolt)				41-180	C-103K3
	C-7500 1 5/8 TR				41-230	C-103K2.5
	Caprice				31-140	C-332K13
	G-30 Vans	1984 - 1999			31-140	C-347K13
	G-31 Vans	1984 - 1999			31-140	C-347K13
	Geo Tracker (4X2 & 4X4)	1990 - 1999			30-070	G-303K12
	K-3500 Pickup 4X4	2000			31-140	C-304K13
	P-12 Chassis ( Solid I-Beam Axle)	1998			41-230	V-917K3
	P-30, P-32, P-37, P-Cutaway & Workhorse P-32				31-140	P-30KB13
	P-30, P-32, P-37, P-Cutaway & Workhorse P-32	2004 - 2005			31-140	P-30KB14
	P-32 Chassis				31-140	P-30KB13
	P-32 Chassis	2004 - 2005			31-140	P-30KB14
	P-72 Chassis	1996 - 1997			41-230	G-002K1
	P-92 Chassis	1996 - 1997			41-230	G-002K1
	Silverado 1500 Pickup 4X4	1984			31-140	Z-310K13
	Suburban & Pickups 4X2	1992 1997			31-140	C-341K13
	Suburban & Pickups (1500, 2500, & 3500 Series 4X2)	1989 & Prior			31-140	C-30KA13
	Suburban & Pickups (1500, 2500, & 3500 Series 4X2)	1990 - 1997			31-140	C-318K13
	Suburban & Pickups 4X4	1992 - 2000			31-140	C-340K13
	Suburban (Tie Rod In Front)				31-140	C-333K13
	Suburban 4X2 & Pickups 4 X 2	1998 - 1999			31-140	C-346K12
	Suburban 4X4 (Tie Rod In Front)	1973 - 1991			31-140	C-305K13
	Suburban C2500 Series 4X2 Gas	1990			31-140	C-350K12
<b>Coachman</b>	<b>Aurora (19.5 inch wheels)</b>	<b>2008</b>	<b>Ford</b>	<b>F-53</b>	<b>SEE FORD CHASSIS</b>	<b>SEE FORD CHASSIS</b>
	Aurora	2008	Workhorse	W22/24	41-230	W-104K1.5
	Catalina	1989	Chevrolet	P-30	31-140	P-30KB13
	Cross Country	2008 - 2016	Freightliner	XC	41-230	F-143K2
	Encounter (9,000 lb. Axle with 22.5 inch wheels)	2011 - 2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Enounter (with 22.5" Wheels)	2015 - 2016	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Epic 3580 (19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Freelander	2002 - 2015	Chevy	4500	31-140	C-354K14
	Freelander	2010 - 2015	Ford	E-450	31-140	E-353K14
	Freelander	2010 -2015	Ford	E-350	31-140	E-353K14
	Leprechaun	2014 - 2015	Ford	E-450	31-140	E-353K14
	Mirada (7,000 lb. Axle with 19.5 inch wheels)	2011 - 2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Mirada (9,000 lb. Axle with 22.5 inch wheels)	2011 - 2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Mirada	2000 and Up	Workhorse	P-Series	31-140	P-30KB13
	Pathfinder	2008 - 2012	Freightliner	XC	41-180	F-143K2
	Sport Coach	2008 - 2011	Freightliner	XC	41-230	F-143K2
<b>Country Coach</b>	<b>Country Coach Affinity (Dana Kirkstall I. F. S.)</b>	<b>2000 - 2001</b>			<b>41-230</b>	<b>C-180K2.5</b>
	Country Coach Allure & Intrigue	1999			41-230	C-112K4
<b>Country Coach</b>	<b>Country Coach Allure (Neway I. F. S.)</b>	<b>2000 - 2006</b>			<b>N/A</b>	<b>N/A</b>
	Country Coach Inspire (Neway I. F. S.)	2006			N/A	N/A

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Country Coach Intrigue (Neway I. F. S.)	2000 - 2001			N/A	N/A
	Country Coach Intrigue	1994 - 1996			41-230	F-53K2
	Country Coach Intrigue	1997			41-230	F-53K4
	Country Coach Intrigue	1998			41-230	R-104K4
	Country Coach Magna & Affinity (Dana Kirkstall I. F. S.)	2002			41-230	C-180K3.5
	Country Coach Magna (Dana Kirkstall I. F. S.)	2000 - 2001			41-230	C-180K2.5
	Country Coach Tribute 260	2007			41-230	
<b>Crown</b>	Vogue (With Airbags)				41-230	V-917K2
	Vogue	1994 - 1999			41-230	G-002K2
	Vogue (with Independent Front Suspension)					N/A
<b>Damon</b>	Astoria	2005 - 2012	Freightliner	XC	41-230	F-143K3
	Avanti		Freightliner	MCL	41-180	55-130-5 / 55-206 / 1375K
	Avanti	2009	Workhorse	W16	41-230	W-140K1.5
	Challenger	Through 2010	Workhorse	W20/22	41-230	W-104K1.5
	Challenger	2011	Ford	F-53 w/ 9k	SEE FORD CHASSIS	SEE FORD CHASSIS
	Daybreak		Workhorse	W16/18	41-230	W-104K1.5
	Daybreak		Workhorse	P-32	31-140	P-30KB13
	Escaper	2002 - 2005	Freightliner	XC	41-230	F-143K3
	Escaper LX400 Neway 114 (Independent Front Suspension)	2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Escaper LX400 ZF (Independent Front Suspension)	2004	Freightliner	XC - IFS		N/A
	Escaper LX400	2005	Freightliner	XC	41-230	F-143K3
	Essense		Freightliner	XC	41-230	F-143K3
	Intruder 373 (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Intruder 391		Workhorse	W24	41-230	W-104K1.5
	Intruder		Workhorse	W20/22	41-230	W-104K1.5
	Outlaw		Workhorse	W22/24	41-230	W-104K1.5
	Outlaw (with 19.5 inch wheels)	2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Outlaw	2009	Freightliner	MC-FRED	41-230	H-190K2.5
	Tuscany	2005 - 2012	Freightliner	XC	41-230	F-143K3
	Ultra Sport	2002 - 2005	Freightliner	XC	41-230	F-143K3
<b>Dodge</b>	"B" Series Class "C" Vans & Mini Motorhomes	1977 - 1996			31-140	D-307K13
	"D" Series Vans (100,150,250,300 And 350)				31-140	D-306K13
	1500 Series 4X2 (Gas Or Diesel)	1999 - 2001			31-140	D-342K12
	1500 Series 4X4 (Gas Or Diesel)	1998			31-140	D-341K12
	1500,2500 & 3500 Series 4X4 (Gas Or Diesel) Including Dually	1999 - 2001			31-140	D-341K13
	2500 & 3500 Series 4X2, 4X4, Dually (DOES NOT Fit Some 2001 Models)	1999 - 2007			31-140	D-342K14
	Dakota 4X4				31-140	D-338K12
	M300-M600 ( 1-1/4" Tie Rod)				41-140	JD-800K1
	Maxivans 3500 Series	1996 & Prior			31-140	M-307K13
	Maxivans 3500 Series	1997 - 2001			31-140	D-343K13
<b>Dodge</b>	Maxivans 3500 Series (Pleasureway Specific)	1997 - 2002			31-140	D-343PK13
	Extended Cab 250 Pick-up 4 x 4				41-140	F-127K2
	Ram 1500 Series 4X2 (with 1-1/4" Tie Rod)	1994			31-140	D-344K13



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Ram 1500 Series 4X4 (V-8)	1998			31-140	D-342K12
	Ram 2500 Series 4X4, 3500 (Also Other Full Size 4X4 Pickups)	1995 - 2001			31-140	Z-310K13
	Ram Pickup 2500 4 X 2 (Diesel)	1996			31-140	D-333K14
	Ram Pickups & Duallys (150, 250 And 350 Series)	1991 - 1994			31-140	D-325K13
	Ram Pickups 1500 & 2500 Series 4X2	1995 - 1997			31-140	D-344K13
	Ram Pickups 3500 Series 4X2 1995-2001	2001			31-140	D-328K14
	Ram Van 3500 - Leisure Travel Van 2B 1 3/16 T.R. (not 4X4 and not Dually)	1996			31-140	D-307K13
	Ram Vans 250,350 & Ram Vans 1500 Series	1978 - 1999			31-140	R-350K13
	Sprinter Series - Rack & Pinion Steer		Mercedes			N/A
	Van (250) 3/4 Ton	1989			31-140	D-319K14
	Vironex (Aerocrusier, Explorer & Americoach (with 1-1/4" Tie Rod)				31-140	VX-330K14
	Vironex (Aerocrusier, Explorer & Americoach (with 1-1/8" Tie Rod)				31-140	VX-330K13
<b>Dynomax</b>	<b>Country Coach Affinity (Dana Kirkstall I. F. S.)</b>	<b>2000 - 2001</b>			<b>41-230</b>	<b>C-180K2.5</b>
	Country Coach Allure & Intrigue	1999			41-230	C-112K4
	Country Coach Allure (Neway I. F. S.)	2000 - 2006			N/A	N/A
	Country Coach Inspire (Neway I. F. S.)	2006			N/A	N/A
	Country Coach Intrigue (Neway I. F. S.)	2000 - 2001			N/A	N/A
	Country Coach Intrigue	1994 - 1996			41-230	F-53K2
	Country Coach Intrigue	1997			41-230	F-53K4
	Country Coach Intrigue	1998			41-230	R-104K4
	Country Coach Magna & Affinity (Dana Kirkstall I. F. S.)	2002			41-230	C-180K3.5
	Country Coach Magna (Dana Kirkstall I. F. S.)	2000 - 2001			41-230	C-180K2.5
<b>DYNAMAX</b>	<b>Grandsport</b>	<b>2007</b>	<b>Freightliner</b>	<b>M2/10K lb</b>	<b>41-230</b>	<b>V-917K3</b>
<b>Eagle</b>	<b>Bus (Model 01 Or 10)</b>				<b>41-230</b>	<b>E-152K</b>
	Bus (Model 05) (with 1-1/2" Tie Rod)	1967 - 1973			41-230	E-141K
	Bus (Model 05) (with 1-3/4" Tie Rod)	1967 - 1973			41-230	E-141K3
	Silver Eagle Model 05 (with 1-1/4" Drag Link)	1967 & 1977			41-230	E-141K
<b>Entegra</b>	<b>Anthem</b>	<b>2009 - 2010</b>	<b>Spartan</b>	<b>MMGT Tuthill 1460</b>	<b>41-230</b>	<b>S-1460K4</b>
	Anthem	2011 - 2012	Spartan	Hendrickson IFS		
	Anthem	2013	Spartan	MMGT I-Beam	41-230	S-124K3
	Anthem (IFS)	2013 - 2014	Spartan	MM Tuthill, Gran., Reyco	41-230	S-1460K4
	Aspire 40/42	2009 - 2012	Freightliner	XC	41-230	F-143K2
	Aspire 40/42	2013-2015	Spartan	MMGT I-Beam Axle	41-230	S-124K3
	Cornerstone	2009 - 2013	Spartan	K2/K3 - Tuthill 1660	41-230	S-1460K4
	Insignia	2009 - 2012	Freightliner	XC	41-230	F-143K2
<b>Fleetwood</b>	<b>American Dream</b>	<b>1999</b>	<b>Spartan</b>	<b>Mnt Master</b>	<b>41-230</b>	<b>S-115K2.5</b>
<b>Fleetwood</b>	<b>American Eagle (with Independent Front Suspension ZF)</b>	<b>2004 - 2005</b>	<b>Freightliner</b>	<b>XC - IFS</b>		<b>N/A</b>
	Americian Eagle	1993	Spartan	MM Chassis	41-230	S-112K3
	American Eagle (with Independent Front Suspension - Reyco/Tuthill 1460)	2005 - 2006	Spartan	MM Reyco/Tuthill 1460	41-230	S-1460K4
	American Tradition (with Independent Front Suspension ZF)	2004 - 2005	Freightliner	XC - IFS		N/A
	Bounder		Workhorse	W20/24	41-230	W-104K1.5



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE-T PLUS	Mounting Hardware Kit
	Bounder	2002 - 2010	Freightliner	XC	41-230	F-143K2
	Bounder 35 E (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Bounder (with 22.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Discovery	2002 - 2010	Freightliner	XC	41-230	F-143K2
	Discovery	2011 - 2012	Spartan	MM I-beam	41-230	S-124K3
	Excursion	2003 - 2015	Freightliner	XC	41-230	F-143K2
	Excursion (with 19.5 inch wheels)	2013	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Excursion (Reyco Granning, Straight I-beam Axle)	2005	Spartan	MM 1200	41-230	S-124K3
	Expedition	2002 - 2010	Freightliner	XC	41-230	F-143K2
	Fiesta		Workhorse	W16/18	41-230	W-104K1.5
	Fiesta LX		Workhorse	W20/22	41-230	W-104K1.5
	Flair		Workhorse	W20/22	41-230	W-104K1.5
	Flair 33R (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Montara	1989 - 1999	Chevrolet	G-30	31-140	C-347K13
	Pace Arrow (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Pace Arrow		Workhorse	W22/24	41-230	W-104K1.5
	Pace Arrow 38P		Workhorse	W24	41-230	W-104K1.5
	Pace Arrow		Chevrolet	P30 / P32	31-140	P-30KB13
	Providence	2003 - 2010	Freightliner	XC	41-230	F-143K2
	Providence	2011 - 2012	Spartan	MMGT I-beam	41-230	S-124K3
	Revolution	2002 - 2005	Freightliner	XC	41-230	F-143K2
	Revolution LE		Spartan	MM I-Beam	41-230	S-124K3
	Southwind		Workhorse	W20/W22	41-230	W-104K1.5
	Southwind (with 19.5 inch wheels)	Up to 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Southwind (with 22.5 inch wheels)	Up to 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Storm		Workhorse	W20/22	41-230	W-104K1.5
	Terra		Workhorse	W16/22	41-230	W-104K1.5
	Terra (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>FMC</b>	Alternative For FMC Motorhomes (with Fresh Water Tank In Front)				31-140	F-409K13
	FMC Motorhomes				41-230	F-314K
<b>Ford</b>	Bronco Xlt 4x4 (Tie Rod In Front Of Axle) Twin I-Beam				31-140	F-35092K13
	Bronco Xlt 4x4 A-Frame S.E.	1995			31-140	F-35092K13
	E-150 Vans	1998 - 1999			31-140	E-35092DK14
	E-150 Econoline Vans (T.R. in front of Axle)	1987 - 1991			31-140	E-350K13
	E-250 Econoline Vans (T.R. in front of Axle)	1987 - 1991			31-140	E-350K13
	E-250 Class C (V10)	1997 - 2008			31-140	E-340K13
	E-33 Twin I Beam Class A Motorhome (On Class C Chassis)				31-140	E-35092K13
	E-350 Econoline Vans (with Tie Rod in Front of Axle)	1987 - 1991			31-140	E-350K13
<b>Ford</b>	E-350 Diesel	1992 - 1999			31-140	E-35092DK14
	E-350 Gas	1992 - 1999			31-140	E-35092K13
	E-350 Class C (V10)	1997 - 2009			31-140	E-340K13
	E-350 Class C (V10)	2010 - 2016			31-140	E-353K14
	E-450 Class C (V10)	1997 - 2009			31-140	E-340K13
	E-450 Class C (V10)	2010 - 2016			31-140	E-353K14



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE-T-PLUS	Mounting Hardware Kit
	Expedition & Truck 4x4 (Gas & F-250)	1997 - 2003			31-140	F-345K12
	F-150 Twin I-Beam (Gas)	1992			31-140	F-35092K13
	F-150 4x2 or 4x4 (Gas) (with Tie Rod In Front Of Axle)	1994			31-140	F-337K13
	F-150 (with Tie Rod In Front Of Axle) Gas	1991 & Prior			31-140	E-350K13
	F-150 4 x 2 (Gas) (All with 1" Tie Rod)	1997 - 2002			31-140	F-348K12
	F-150 Lariat & Expedition (All with 1" Tie Rod)Gas 4 x 2	1997 - 2002			31-140	E-350K13
	F-150 (Gas)	1985 - 1989			31-140	F-323K13
	F-250 Twin I-Beam (Gas)	1992			31-140	F-35092K13
	F-250 Leaf Spring Suspension (Gas)				31-140	F-316K13
	F-250 Diesel (with Tie Rod in Front of Axle)	1991 & Prior			31-140	E-350K13
	F-250 (Diesel)	1985 - 1989			31-140	F-323K13
	F-250 4x2 (Gas Or Diesel) (with Twin I-Beam)	1999 - 2011			31-140	F-349K14
	F-250 (Tube Axle Coil Springs) 4x4	2006 - 2013			31-140	F-193K3-B
	F-250 4x4	1999 - 2004			41-140	F-127K2
	F-250 (Round Axle with Leaf Springs) 4 x 4	1999 - 2004			41-140	F-127K2
	F-250 4x2	1992 - 1998			31-140	F-332K13
	F-250 4x4 (with Leaf Springs) (Gas Or Diesel)				31-140	F-334K13
	F-250 Tube Axle & Coil Springs 4 x 2 ONLY				41-140	F-193K3
	F-350 Tube Axle & Coil springs 4 x 2 ONLY				41-140	F-193K3
	F-350 (Diesel)	1985 - 1989			31-140	F-323K13
	F-350 (Diesel)	1990 - 1998			31-140	F-323K13
	F-350 (Diesel) (with Tie Rod in Front Axle)	1991 & Prior			31-140	E-350K13
	F-350 1-Ton Pickups (with Tie Rod In Front Of Axle)	1991 & Prior			31-140	E-350K13
	F-350 4x4 Leaf Springs (Gas Or Diesel)	1998 & Prior			31-140	A-314K
	F-350 4x4 (Round Axle with Leaf Springs)	1999 - 2004			41-140	F-127K2
	F-350 4x2 (Gas or Diesel) (with Twin I-Beam)	1999 - 2011			31-140	F-349K14
	F-350 (Tube Axel w/ Coil Springs) 4x4 only	2006 - 2013			41-140	F-193K3-B
	F-450 Tube Axle & Coil Springs 4 x 4 Only				41-140	F-193K3-B
	F-450 (Tube Axle with Coil Springs) 4x2 only	2006 - 2013			41-140	F-193K3
	F-450 4x2 (Gas or Diesel) (with Twin I-Beam)	1999 - 2011			31-140	F-349K14
	F-450 (Round Axle with Leaf Springs) 4 x 4	1999 - 2004			41-140	F-127K2
	F-450 Super Duty 4 x 4	2007			41-140	E-353K14
	F-53 Class A Superduty Motorhome (V-8 & V10)	1989 - 1999			41-140	F-53K2
	F-53 Class C (22.5" Wheels) (29ft or shorter vehicle length)	2000 - 2014			41-140	F-53K2.5
	F-53 Class A (22.5" Wheels) (V-10) (31ft. - 34ft. In length)	2000 - 2014			41-180	F-53K2.5
	F-53 Class A (22.5" Wheels) (V-10) (35 feet or longer)	2000 - 2014			41-230	F-53K2.5
	F-53 Class C (19.5" Wheels) (29ft or shorter vehicle length)	2000 - 2014			41-140	F-119K2.5
	F-53 Class A (19.5" Wheels) (V-10 ) (31ft. - 34ft. In length)	2000 - 2014			41-180	F-119K2.5
	F-53 Class A (19.5" Wheels) (V-10 ) (35 feet or longer)	2000 - 2014			41-230	F-119K2.5
	F-53 Class C ANY WHEEL SIZE (29ft or shorter vehicle length)	2015 - 2016			41-140	F-53K2.5
	F-53 Class A ANY WHEEL SIZE (31ft. - 34ft. In length)	2015 - 2016			41-180	F-53K2.5
	F-53 Class A ANY WHEEL SIZE (35 feet or longer)	2015 - 2016			41-230	F-53K2.5
<b>Ford</b>	F-53 Class A (with 1 1/2" Tie Rod) (19.5" Wheels) (V-10)	2000 - 2015			41-180	F-119K2
	F-550 Tube Axle & Coil Springs 4 x 4				41-140	F-193K3-B
	F-550 Straight Axle Model	2001 - 2004			41-140	S-124K2
	F-550 (Round Axle with Leaf Springs) 4 x 4	1999 - 2004			41-140	F-127K2

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	F-550 (Tube Axle with Coil Springs) 4x2	2006 - 2013			41-140	F-193K3
	F-650 4x2	2002 - 2014			41-140	G-002K2.5
	F-750				41-140	G-002K2.5
	L.T.D./ Mercury / Grand Marquis / Lincoln	1991 & Prior			31-140	F-333K13
	L.T.D./ Mercury / Grand Marquis / Lincoln	1992 - 2001			31-140	F-341K13
<b>Forest River</b>	<b>Berkshire</b>	<b>2007 - 2015</b>	<b>Freightliner</b>	<b>XC</b>	<b>41-230</b>	<b>F-143K2</b>
	Charleston	2006 - 2010	Freightliner	XC	41-230	F-143K2
	Forester	2015 - 2016	Ford	E-450	31-140	E-353K14
	Georgetown	2000			41-230	S-124K2
	Georgetown	2007 - 2010	Workhorse	UFO	41-230	H-190K2.5
	Georgetown (with 22.5 inch wheels)	2011 - 2016	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Georgetown (with 19.5 inch wheels)	2007 - 2016	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Reflection	2002 - 2004	Freightliner	XC	41-230	F-143K2
	Tsunami Neway 114 Independent Front Suspension	2002 - 2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Tsunami Independent Front Suspension ZF Model	2004 - 2007	Freightliner	XC - IFS		N/A
<b>Foretravel</b>	<b>U-225, U-240 Oshkosh with Torsolatic</b>				<b>41-230</b>	<b>G-002K2</b>
	Unicoach 275/ 295 / 320				41-230	U-148K
	Unihome U-280,U-300 & U320				41-230	U-148K
<b>Four Winds</b>	<b>Chalet</b>	<b>2009 - 2016</b>	<b>Ford</b>	<b>E-350</b>	<b>31-140</b>	<b>E-340K13</b>
	Chalet	2009 - 2016	Ford	E-450	31-140	E-353K14
	Chalet	2009 - 2016	Chevy	4500	31-140	C-354K14
	Chateau	2008	Chevy	Kodiak 5500	41-180	C-103K3
	Chateau	2010 - 2016	Ford	E-450	31-140	E-353K14
	Chateau	2010 - 2016	Ford	E-350	31-140	E-353K14
	Chateau	2010 - 2016	Chevy	4500	31-140	C-353K14
	Fun Mover		Workhorse	W22/24	41-230	W-104K1.5
	Fun Mover (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Fun Mover 42		Ford	F-750	41-180	G-002K2.5
	Hurricane		Workhorse	W16/18	41-230	W-104K1.5
	Hurricane		Workhorse	W20/22	41-230	W-104K1.5
	Hurricane (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Magellan		Workhorse	W20/22	41-230	W-104K1.5
	Magellan 38E		Workhorse	W24	41-230	W-104K1.5
	Windsport		Workhorse	W20/22	41-230	W-104K1.5
<b>Freightliner</b>	<b>26000 Series (with 1 1/2 inch Tie Rod)</b>				<b>41-230</b>	<b>F-143K2</b>
	26000 Series (with 1 1/4 inch Tie Rod)				41-230	F-143K1
	26000 Series (with 1 3/4 inch Tie Rod)				41-230	F-143K3
	Airstream Land Yacht Diesel XC				41-230	F-143K2
<b>Freightliner</b>	<b>FI 50 - FI 60</b>				<b>41-230</b>	<b>JD-800K2</b>
	FI 50 - FI 60 Med Duty	1997 - 1999			41-230	F-126K1
	FI 50 - FI 60 (with Drop From Bottom Of Spring To Top Of Tie Rod)	1996			41-230	F-169K2
	FI 50	2000			41-230	F-167K2
	FI 70 (with F961 Rockwell Axle)				41-230	R-104K2



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	FI 70 (with 9,000 lb. Axle)	2000 - 2001			41-230	V-814K2
	FI 80 (with 961 Rockwell Axle)				41-230	R-104K4
	FRED	2007			41-230	H-190K2.5
	M-2 Chassis (with 8,000 lb.)				41-180	JD-800K3
	M-2 Chassis (with 10,000 lb. Axle)				41-180	V-917 K3
	Most Models with Leaf Springs				41-230	JD-800K2
	XC 1998 - Tiffin Allegro Bus	1998			NO FIT	NO FIT
	XC Line Leaf Springs, Straight Axle, Diesel Puller (with 1" Tie Rod)				41-230	JD-800K1
	XC, VC & H Lines (Intermediate Airbags) (with 1 1/4" Tie Rod)				41-230	F-143K1
	XC, VC & H Lines (Intermediate Airbags)(with 1 1/2" Tie Rod)				41-230	F-143K2
	XC, VC & H Lines (Intermediate Airbags)(with 1 3/4" Tie Rod)				41-230	F-143K3
	XCS Series (with 1 1/2" Tie Rod) (with Air Bags)	2000 - 2005			41-230	F-143K2
	XCS Series (with 1 1/2" Tie Rod) (with Leaf Springs)	2000 - 2005			41-230	F-104K2
	XCS Series (with 1 1/4" Tie Rod) (with Air Bags)	2000 - 2005			41-230	F-143K1
	X-Press				41-230	V-814K2
<b>Special</b>						
<b>Application: Freightliner</b>	<b>Neway Independent Front Suspension (IFS)</b>				<b>42-230</b>	<b>F-IFSK2 or K2SG *</b>
<b>Georgie Boy</b>	<b>Bellagio</b>	<b>2003 - 2005</b>	<b>Freightliner</b>	<b>XC</b>	<b>41-230</b>	<b>F-143K2</b>
	Cruise Air	2002	Freightliner	XC	41-230	F-143K2
	Cruise Air XL	2003 - 2005	Freightliner	XC	41-230	F-143K2
	Cruise Master 3740 FWS		Workhorse	UFO	41-230	H-190K2.5
	Landau		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Pursuit (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>Gillig</b>	<b>Gas</b>	<b>1994 &amp; Prior</b>			<b>41-230</b>	<b>G-002K2</b>
	9000 Lb. Axle (Diesel)				41-230	G-001K3
	Affiniti	1996			41-230	S-124K2
	Country Coach	1996			41-230	S-124K3
	Diesel (with Airbags)	1994 & Prior			41-230	G-001K3
	Diesel (with Leaf Springs)	1994 & Prior			41-230	G-002K3
<b>GMC Motorhome</b>	<b>Tornado Front Wheel Drive ( 403 Or 455 Cubic Inch Motor)</b>				<b>31-140</b>	<b>G-315K</b>
	C7500 - See Chevy Section					
	4106	1964	GMC		41-230	G-002K3
<b>Gulf Stream</b>	<b>Atrium</b>	<b>2003 - 2006</b>	<b>Freightliner</b>	<b>XC</b>	<b>41-230</b>	<b>F-143K2</b>
	Atrium (Independent Front Suspension) ZF Model	2004	Freightliner	XC - IFS		N/A
	Bounty Hunter (with 19.5 inch wheels)	2008 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>Gulf Stream</b>	<b>Bounty Hunter</b>	<b>2008 - 2010</b>	<b>Freightliner</b>	<b>MC-FRED</b>	<b>41-230</b>	<b>H-190K2.5</b>
	Caribbean	2009	Freightliner	XC	41-230	F-143K2
	Constellation (Independent Front Suspension) ZF Model	2009	Freightliner	XC-IFS	N/A	N/A
	Crescendo	2004 - 2010	Freightliner	XC	41-230	F-143K2
	Crescendo	2006 - 2010	Freightliner	MC-FRED	41-230	H-190K2.5
	Crescendo	2008 - 2010	Workhorse	R Series	41-230	S-124K3.5



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE-T PLUS	Mounting Hardware Kit
	Friendship	1990	Spartan	K-Line Eaton	41-230	JD-800K
	Friendship	2002 - 2005	Freightliner	XC	41-230	F-143K2
	Friendship (Independent Front Suspension) ZF Model	2004	Freightliner	XC - IFS		N/A
	Friendship G	2006 - 2007	Freightliner	XC	41-230	F-143K2
	Independence		Workhorse	W20/24	41-230	W-104K1.5
	Independence	2002	Freightliner	XC	41-230	F-143K2
	Independence Model 8295, 8330 (with 19.5 inch wheels)	2008 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Independence Model 8367, 8360, 8359 (with 22.5 inch wheels)	2008 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Independence Model 8327	2008 - 2010	Freightliner	MC-FRED	41-230	H-190K2.5
	Montaj (with 19.5 inch wheels)	2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Senic Cruiser	2002 - 2006	Freightliner	XC	41-230	F-143K2
	Senic Cruiser (Independent Front Suspension) ZF Model	2004	Freightliner	XC - IFS		N/A
	Sun Sport (with 19.5 inch wheels)	2008 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Sun Sport	2008 - 2010	Workhorse	W20/22	41-230	W-104K1.5
	Sun Sport	2009	Freightliner	MC-FRED	41-230	H-190K2.5
	Sun Voyaer	1996 - 1998	Spartan	EXP / Mtn. Master	41-230	G-002K3.5
	Sun Voyager (with 19.5 inch wheels)	2007 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Sun Voyager	2007 - 2012	Workhorse	W20/24	41-230	W-104K1.5
	Sun Voyager	2009	Freightliner	MC-FRED	41-230	H-190K2.5
	Tour Master	2006 - 2008	Freightliner	XC	41-230	F-143K2
	Tour Master (Independent Front Suspension) ZF Model	2008	Freightliner	XC - IFS		N/A
	Yellowstone	2002 - 2012	Freightliner	XC	41-230	F-143K2
	Yellowstone (with 19.5 inch wheels)	2008 - 2012	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Yellowstone	2008 - 2012	Freightliner	MC-FRED	41-230	H-190K2.5
	Yellowstone	2008 - 2010	Workhorse	R Series	41-230	S-124K3.5
<b>Hawkins Motorcoach (HMC)</b>		1994 - 1996	Oshkosh	X-Series	41-230	JD-800K1
<b>Holiday Rambler</b>	Admiral (with 19.5 inch wheels)	2008	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Admiral	2008	Workhorse	W20/22	41-230	W-104K1.5
	Admiral 40 PDQ (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Admiral SE		Workhorse	W20/22	41-230	W-104K1.5
	Admiral SE 30PDD (W18)		Workhorse	W16/18	41-230	W-104K1.5
	Admiral SE 30pPDD (W18) A-Frame		Workhorse	P32	31-140	P-30KB14
	Ambassador		Roadmaster	RR8R	41-230	G-002K4
	Ambassador (with Air Bags) (1 3/8" tie rod)	2001	Roadmaster		41-230	G-002K1.5
	Ambassador (with Air Bags) (with 2" tie rod)	2001 - 2002	Roadmaster		41-230	G-002K4
	Arista (with 19.5 inch wheels)	2008	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Arista	2008 - 2010	Workhorse	W18/W20/W22	41-230	W-104K1.5
<b>Holiday Rambler</b>	Endeavor		Roadmaster	RR8R/RR10R	41-230	G-002K4
	Imperial		Roadmaster	RR10S	41-230	G-002K4
	Imperial (with Air Bags) (with 1 3/4" tie rod)	2001 - 2001	Roadmaster		41-230	G-002K3
	Imperial 40 foot	1997	Roadmaster	RR8R	41-230	G-002K4
	Imperial	1995-1996	Spartan	MM-Eaton I Beam	41-230	S-112K3
	Navigator		Roadmaster	S-SERIES	41-230	G-002K4
	Neptune		Roadmaster	RR4R	41-230	G-002K3




# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Neptune (with Air Bags) (Westport Axle with 1 1/2" tie rod)	2003	Roadmaster		41-230	G-002K2
	Scepter		Roadmaster	RR8S	41-230	G-002K4
	Trip		Navistar	Roadmaster	41-230	S-124K3
	Vacationer	2008	Roadmaster	RSR	41-230	F-104K3
	Vacationer	2008	Workhorse	UFO	41-230	H-190K2.5
	Vacationer (with 22.5" Wheels)	2014	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>International</b>	<b>Medium Duty Truck</b>	<b>1994</b>			<b>41-230</b>	<b>F-104K1</b>
	Harvester 4700 (with 8,000 Lb front Axle)				41-230	V-814K3
	4400 - 4700 Trucks	2003 - 2005			41-230	G-002K3
	4300 - 4700 Trucks, Ambulance, School Bus	2006 - 2008			41-230	I-002K3
	5500i				41-230	G-002K2
	7400 Trucks				41-230	V-917K4
	7600 Trucks				41-230	55-116-8 / 55-208 / 1875K
	9200-9400 Trucks (check Tie Rod Diameter 1 1/2 - 1 3/4 inches)				41-230	G-002K2 / K3
	D-Series Bus (Diesel Pusher)				41-230	I-001K3
<b>Isuzu</b>	<b>Safari Trek &amp; Npr</b>				<b>31-140</b>	<b>I-324K14</b>
<b>Itasca</b>	<b>Cambra 2011</b>		<b>Ford E - c/50</b>	<b>Ford</b>	<b>31-140</b>	<b>E-353K14</b>
	Ellipse	2008 -2010	Freightliner	XC	41-230	F-143K2
	Horizon	2004 - 2005	Freightliner	XC	41-230	F-143K2
	Horizon (Independent Front Suspension) ZF Model	2004 - 2010	Freightliner	XC - IFS		N/A
	Latitude	2008 - 2010	Freightliner	XC	41-230	F-143K2
	Latitude	2008 - 2010	Workhorse	UFO	41-230	H-190K2.5
	Meridian	2002 - 2013	Freightliner	XC	41-230	F-143K2
	Suncruiser (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Suncruiser		Workhorse	W20/22	41-230	W-104K1.5
	Sunova (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Sunova		Workhorse	W20/22	41-230	W-104K1.5
	Sunrise (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Sunrise		Workhorse	W20/22	41-230	W-104K1.5
<b>Jayco</b>	<b>Seneca</b>	<b>2012</b>	<b>Freightliner</b>	<b>M-22</b>	<b>41-180</b>	<b>JD-800K3</b>
	Seneca C-5500 (Some may require new U-bolt)		Chevrolet	C-5500	41-180	C-103K3
	Insignia	2009 - 2012	Freightliner	XC	41-230	F-143K2
	Precept (with 22.5" front wheels) (V-10)	2014 - 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Precept (with 19.5" front wheels) (V-10)	2014 - 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>Jeep</b>	<b>Cherokee 4x4</b>	<b>1990 - 2000</b>			<b>31-140</b>	<b>J-209K</b>
	Wrangler 4x4	1990 - 2000			31-140	J-209K
<b>John Deere</b>	<b>Ford 460 Engine (with 1 1/4" Tie Rod)</b>				<b>41-230</b>	<b>JD-800K1</b>
<b>Kenworth</b>	<b>Spicer E-1320 (I Axle &amp; 4 Springs)</b>	<b>2000</b>			<b>41-230</b>	<b>K-170K3</b>
	Model 900 (with 12,000 lb. Axle)	2000			41-230	G-002K3.5

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model		Mounting Hardware Kit
	Most				41-230	G-002K3
<b>King of the Road</b>	Genesis	2004	Freightliner	XC	41-230	F-143K2
	Genesis (Independent Front Suspension) ZF Model	2005 - 2007	Freightliner	XC - IFS		N/A
<b>Magnum</b>	Beaver BS300		Magnum		41-230	G-002K2
	Beaver Marquis (Diamante Edition)	1998	Magnum		41-230	S-153K4
	Beaver Monterey Magnum Chassis	1999 - 2000	Magnum		41-230	JD-800 K1
	Beaver Patriot (with 1 7/8" Tie Rod)	1996 & Prior	Magnum		41-230	G-002K3.5
	Beaver Patriot (with 1 3/4" Tie Rod)	1996 & Prior	Magnum		41-230	G-002K3
	Beaver Patriot	1997 - 2002	Magnum		41-230	G-002K4
	Cheetah Torsion Suspension	2002 & Prior	Magnum		41-230	C-111K2
	Harney Coach Works (Riata)		Magnum		41-230	C-111K2
	Monterey "Blue Streak Chassis"(Beaver)	1997	Magnum		41-230	M-160K2
	Panther 455 (with 1 3/4" Tie Rod)	2001	Magnum		41-230	G-002K3
	Safari (with Leaf Springs) (with 1 3/4 Tie Rod)		Magnum		41-230	G-002K3
	Safari "Continental"	1997	Magnum		41-230	F-142K4
	Safari "Continental" (with 1" Tie Rod)	1999	Magnum		41-230	G-002K12
	Safari	1995	Magnum		41-230	V-814K3
	Safari Renegade		Magnum		41-230	G-002K2
	Safari Sahara Edition (with Leaf Springs)	1994 - 1996	Magnum		41-230	G-002K1
	Safari Sahara Edition	1997 - 1999	Magnum		41-230	M-102K1
	Safari Sahara Velvet Ride (with Wesport Axle) (with 1 1/4 inch tie rod)	1998	Magnum		41-230	1-184K1 (CHECK T.R. DIAM
	Safari Sahara Velvet Ride (with Wesport Axle)	2000	Magnum		41-230	M-184K4
	Safari Serengeti (with 1 1/4 Tie Rod)	1996	Magnum		41-230	F-104K1
	Safari Serengeti "Blue Max" (with 1 1/2" Tie Rod)	1997 - 1999	Magnum		41-230	F-53K2
	Safari Serengeti "Blue Max" (with 2" Tie Rod)	2000	Magnum		41-230	F-53K4
	Safari Velvet Ride (with Air Bags)	1998 - 1999	Magnum		41-230	F-53K4
	Safari Velvet Ride (with B.F.Goodrich TorSlatic)	1994	Magnum		41-230	S-153K2
	Safari Velvet Ride	1995	Magnum		41-230	F-142K1
	Safari Velvet Ride	1996	Magnum		41-230	S-124K2
	Safari Zanzibar (with Westport Axle) (with 1" Tie Rod)	2000	Magnum		41-230	S-103K1
	Safari Zanzibar (with 1 3/4" Tie Rod)	2000 - 2002	Magnum		41-230	G-002K3
<b>Mandalay Coach</b>	Mandalay (Independent Front Suspension) ZF Model	2004 - 2010	Freightliner	XC - IFS		N/A
	Presidio		Workhorse	R Series	41-230	S-124K3.5
	Presidio	2006 - 2009	Freightliner	XC	41-230	F-143K2
<b>Mandalay Coach</b>	Valencia	2006 - 2007	Freightliner	XC	41-230	F-143K2
<b>Mercedes Benz</b>	Sprinter (Independent Front Suspension)		Mercedes	Sprinter		N/A
<b>Monaco</b>	Camelot		Roadmaster	RR8S	41-230	G-002K4
	Caymon		Roadmaster	RR4R	41-230	G-002K3
	Diplomat		Roadmaster	RR8R	41-230	G-002K4
	Monaco Diplomat	1999 - 2001	Roadmaster		41-230	G-002K3
	Dolphin 1994		Oshkosh	1 1/8 TR	41-230	5-206/55-124-5/12-38-1250



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Dynasty		Roadmaster	S-SERIES	41-230	G-002K3
	Dynasty (with Rockwell Front Axle) (with 1 1/2" tie rod)	1993 & Prior	Roadmaster		41-230	G-002K2
	Dynasty (with Rockwell Front Axle) (with 1 3/4" tie rod)	1994 - 2001	Roadmaster		41-230	G-002K3
	Dynasty (with 2" tie rod)	1997	Roadmaster		41-230	G-002K4
	Dynasty	1992 - 1995	Roadmaster		41-230	M-130K2
	Dynasty	1996 - 2001	Roadmaster		41-230	G-002K2
	Executive		Roadmaster	S-SERIES	41-230	G-002K3
	Executive (with 1" tie rod)	2000	Roadmaster		41-230	G-002K12
	Executive (with 1 3/4" tie rod)	1996 - 2001	Roadmaster		41-230	G-002K3
	Executive	1995	Roadmaster		41-230	M-130K2
	Knight		Roadmaster	RR8R	41-230	G-002K4
	Knight (with 1 5/8" tie rod)	2002	Roadmaster		41-230	G-002K2.5
	Knight (with 1 7/8" tie rod)	2001	Roadmaster		41-230	G-002K3.5
	Knight (with 2" tie rod)	2001	Roadmaster		41-230	G-002K4
	Knight (with 1 1/4" tie rod)	2001	Roadmaster		41-230	G-002K1
	Knight (with 1 3/8" tie rod)	2001	Roadmaster		41-230	G-002K1.5
	La Palma		Workhorse	UFO	41-230	H-190K2.5
	La Palma XL Diesel		Roadmaster		41-230	S-147K3
	Monarch (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Monarch		Workhorse	W20/22	41-230	W-104K1.5
	Signature		Roadmaster	S-SERIES	41-230	G-002K3
	Signature (with 1" Tie Rod)	2000	Roadmaster		41-230	G-002K12
	Signature (with Air Bags) (with 2" tie rod)	1995	Roadmaster		41-230	V-917K4
	Simba		Workhorse	W20/22	41-230	W-104K1.5
	Simba	2007	Roadmaster	Raised Rail	41-230	F-143K3
	Trek		Workhorse	W20/22	41-230	W-104K1.5
	Vesta (Must Perform Airbag Deflation Test First - Tran Lines hit Tie Rod)	2006 - 2016	Roadmaster	Roadmaster	41-230	S-124K3
	Vesta (Must Perform Airbag Deflation Test First - Tran Lines hit Tie Rod)		Navistar	Roadmaster	41-230	S-124K3
	Windsor		Roadmaster	RR8S	41-230	G-002K4
	Windsor (with 1 3/4" tie rod)	1996 - 2002	Roadmaster		41-230	G-002K3
	Monaco (with Dana Spicer Front Axle)		Roadmaster		41-230	G-002K3
<b>National RV</b>	<b>Dolphin (with 19.5 inch wheels)</b>		<b>Ford</b>	<b>F-53</b>	<b>SEE FORD CHASSIS</b>	<b>SEE FORD CHASSIS</b>
	Dolphin		Workhorse	W22/24	41-230	W-104K1.5
	Pacifica	2007 - 2008	Freightliner	XC	41-230	F-143K2
	Sea Breeze (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>National RV</b>	<b>Sea Breeze</b>		<b>Workhorse</b>	<b>W20/22</b>	<b>41-230</b>	<b>W-104K1.5</b>
	Surf Side (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Tradewinds (Independent Front Suspension) Neway 114	2002	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Tradewinds (Independent Front Suspension) ZF Model	2006 - 2007	Freightliner	XC - IFS		N/A
	Tropi-Cal	2002 - 2008	Freightliner	XC	41-230	F-143K2
<b>Newell</b>	<b>Newell (Not Independent Front Suspension)</b>				<b>41-230</b>	<b>G-002K2</b>
<b>Newmar</b>	<b>All Star</b>	<b>2008</b>	<b>Spartan</b>	<b>MMME I-Beam</b>	<b>41-230</b>	<b>S-124K3</b>
	Bay Star (with 19.5 inch wheels)	2008 - 2013	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE-T PLUS	Mounting Hardware Kit
	Canyon Star (with 19.5 inch wheels)	2008 - 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Canyon Star (with 22.5 inch wheels)	2008 - 2015	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Canyon Star		Workhorse	W20/22	41-230	W-104K1.5
	Dutch Star	2002	Freightliner	XC	41-230	F-143K2
	Dutch Star (Independent Front Suspension) Neway 114	2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Dutch Star (Independent Front Suspension) ZF Model	2004	Freightliner	XC - IFS	42-230	N/A
	Dutch Star	2008	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Dutch Star (with tag)	2008	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Dutch Star	2013	Freightliner	XCR	41-230	F-143K2.5
	Essex	2008 - 2013	Spartan	K2 Tuthill 1660	41-230	S-1460K4
	Grand Star (with 19.5 inch wheels)	2008 - 2010	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Grand Star	2008 - 2010	Freightliner	MC-FRED	41-230	H-190K2.5
	Grand Star	2008 - 2010	Workhorse	W22/24	41-230	W-104K1.5
	King Aire	Through 2013	Spartan	K3 Dana IFS 84		N/A
	Kountry Star		Workhorse	W24	41-230	W-104K1.5
	Kountry Star (Check Tie Rod Diameter)	2000	Spartan	Summit	41-230	S-181K2
	Kountry Star	2002 - 2005	Freightliner	XC	41-230	F-143K2
	Kountry Star	2005 - 2008	Spartan	MMGT Tuthill 1260	41-230	N/A
	London Aire		Spartan	K3 Dana IFS 84		N/A
	Mountain Aire	1989 - 2001	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Mountain Aire	2002 - 2007	Workhorse	W22/24	41-230	W-104K1.5
	Mountain Aire (Independent Front Suspension) Neway114	2002 - 2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Mountain Aire (Independent Front Suspension) Neway 114	2004	Freightliner	XC - IFS	42-230	F-IFSK2
	Mountain Aire	2008 - 2012	Spartan	K2 Tuthill 1660	41-230	S-1460K4
	Mountain Aire (with tag)	2008 - 2012	Spartan	K2 Tuthill 1660	41-230	S-1460K4
	Mountain Aire	2013	Freightliner	XCR	41-230	F-143K2.5
	Northern Star	2004 - 2005	Freightliner	XC	41-230	F-143K2
	Scottsdale 3303 (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Ventana	2006	Freightliner	XC	41-230	F-143K2
	Ventana	2007 - 2008	Spartan	MM I-Beam	41-230	S-124K3
	Ventana (with Hendrickson Air Tec)	2007 - 2008	Spartan	NVS	41-230	55-194-6 / 55-208 / 1750K
	Ventana LE	2013	Freightliner	XCR	41-230	F-143K2.5
<b>Odessa Ind. / Overland</b>	<b>Lorado Series</b>	<b>1999</b>	<b>Freightliner</b>	<b>XC</b>	<b>41-230</b>	<b>F-143K2</b>
<b>Orion</b>	<b>Orion</b>				<b>41-230</b>	<b>O-104K</b>
<b>Oshkosh</b>	<b>(All Lines) Torsion Suspension</b>	<b>1994</b>			<b>41-230</b>	<b>G-002K1</b>
	K-Line				41-230	JD-800K1
	L-Line (Tie Rod In Front Of Axle)				31-140	L-305K13
	Luxar	1995			41-230	V-917LK3
	M-Line (John Deere) Gas - Except 6300 Front Axle				41-230	JD-800K1
	V-Line Air Ride	1994 & Prior			41-230	V-917K2
	V-Line Anti-Shimmy (Airbags Or Springs)				41-230	V-917CK
	V-Line Anti-Shimmy (Airbags Or Springs)	1995			41-230	V-917CK3
	V-Line Leaf Springs				41-230	V-814K2

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	X-Line	1995			41-230	V-814K3
	X-Line	1995 & Prior			41-230	JD-800K1
<b>Note: Oshkosh</b>	The 12Th Digit Of Vin#					
	1 - 299999 = M Line					
	300000 - 499999 = X Line					
	500000 - 502999 = L Line					
<b>Oshkosh</b>	900000 - 999999 = V Line					
<b>Peterbilt</b>	Most				41-230	G-002K3
<b>Phoenix Cruiser</b>	3100, 2950, 2910, 2900, 2552, 2551, 2300, 2301	2002 - 2009	Ford	E-450	31-140	E-340K14
	3100, 2910, 2800, 2552, 2551	2010 - 2015	Ford	E-450	31-140	E-353K14
	2110, 2400, 2350, 2100	2002 - 2009	Ford	E-350	31-140	E-340K14
	2400, 2350, 2100	2010 - 2015	Ford	E-350	31-140	E-353K14
<b>Prevost</b>	IFS 2000 & Up	2000 & Up			N/A	N/A
	With Power Steering Assist Ram (Except Independent Front Suspension)	1996 - 2002			41-230	P-002K
	W/O Power Assist Ram (Except Independent Front Suspension)				41-230	P-001K
<b>R-Vision</b>	Trail-Lite 241	2001 - 2006	Workhorse	P-32 Series	31-140	P-30KB14
	Trail-Lite	2007	Workhorse	W18	41-230	W-104K1.5
	Trail-Aire	2006	Workhorse	W22	41-230	W-104K1.5
<b>Revcon</b>	Revcon - Toronado Front Wheel Drive IFS				31-140	R-312K13
	Toronado (Independent Front Suspension)	1991 & Prior			31-140	E-350K13
<b>Rexhall</b>	Aerbus T-REX TR35G (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	American Clipper C29 (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Anthem	1998	Spartan	EXP	41-230	G-002K3.5
	GT 375	2008	Workhorse	UFO	41-230	H-190K2.5
	Rexaur 3550 (with 19.5 inch wheels)	2003	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>Rexhall</b>	Vision	1997 - 2006	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
<b>Roadmaster</b>	Airbags	1995 & Prior	Roadmaster		41-230	V-917K2
	Airbags	1995 - 2002	Roadmaster		41-230	V-917K4
	Class A Straight Axle & Air Bags (with 1 3/4" Tie Rod) (Westport Axle)	2000	Roadmaster		41-230	F-143K3
	Class A Straight Axle & Air Bags (with 2" Tie Rod)	2001 - 2002	Roadmaster		41-230	G-002K4
	Class A Straight Axle & Leaf Springs (with 1 3/4" Tie Rod)		Roadmaster		41-140	JD-800K3
	Class A Straight Axle & Leaf Springs (with 1 1/4" Tie Rod)		Roadmaster		41-140	JD-800K1
	Class A Straight Axle & Leaf Springs (with 1 1/2" Tie Rod)		Roadmaster		41-140	JD-800K2
<b>Safari</b>	Cheetah	2003	Roadmaster	M4R	41-230	M-102K1.5
	Cheetah	2004 - 2006	Roadmaster	RR4R	41-230	G-002K3



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Cheetah	2007 - 2008	Roadmaster	RR8R	41-230	G-002K4
	Gazelle		Roadmaster	RR8S	41-230	G-002K4
	Panther	2003 - 2005	Roadmaster	S-SERIES	41-230	G-002K4
	Sahara	2002	Magnum			
	Sahara	2003	Roadmaster	M4R	41-230	M-102K1.5
	Sahara	2004	Roadmaster	RR4R	41-230	G-002K3
	Simba (with 19.5 inch wheels)	2004 - 2008	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Simba	2004 - 2008	Workhorse	W22/24	41-230	W-104K1.5
	Simba FD	2007 - 2008	Freightliner	MC-FRED	41-230	H-190K2.5
	Simba RD	2007 - 2008	Roadmaster	RR4R	41-230	G-002K3
	Trek	2002	Workhorse	P-31 / P-32	31-140	P-30KB14
	Trek (with 19.5 inch wheels)	2002	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Trek	2003 - 2008	Workhorse	W20/22	41-230	W-104K1.5
	Zanzibar	2002	Magnum	Velvet Ride Blue Max	41-230	G-002K1.5
	Zanzibar	2003	Roadmaster	M4R	41-230	M-102K1.5
	Zanzibar	2004	Roadmaster	RR4S	41-230	G-002K3
<b>Shasta</b>	<b>Travelmaster (V-10)</b>	<b>1989 - 2000</b>	<b>Ford</b>	<b>E-350</b>	<b>31-140</b>	<b>E-340K13</b>
<b>Spartan</b>	<b>Alpine Caribbean</b>	<b>2001</b>	<b>Spartan</b>		<b>41-230</b>	<b>G-002K4</b>
	Alpine (with 1 3/4" Tie Rod)	1999	Spartan		41-230	S-126K3
	Alpine (with 2" Tie Rod)	1999	Spartan		41-230	S-126K4
	Alpine GT 2000	2000	Spartan		41-230	S-147K2
	Exp 1997-2001 4th Didget E ( 1-7/8" Tie Rod)	1997 - 2001	Spartan		41-230	G-002K3.5
	Harney Coachworks -VIN Starting (4VZ3L)		Spartan		41-230	F-53K1
	K-Line		Spartan		41-230	JD-800K1
	K-Line American Dream (with 2" Tie Rod)	1994	Spartan		41-230	S-124K4
	K-Line 2000	2000	Spartan		41-230	K-124K2
	K2 Series 1460 Independent Front Suspension (With Out Stabalizer Bar)	2004	Spartan		41-230	S-1460K4
	M-Line (Mountain Master) Granning IFS Model 1200/1320/1370	2000 - 2006	Spartan		26-230	S-115K2.5
	M-Line (Mountain Master)	1995 & Prior	Spartan		41-230	S-112K3
	M-Line (Mountain Master)	1995-1996	Spartan	MM-Eaton I-Beam	41-230	S-112K3
	M-Line (Mountain Master)	1996 - 1997	Spartan		41-230	G-002K3
<b>Spartan</b>	M-Line (Mountain Master)	1998 - 1999	Spartan		41-230	V-917K3
	M-Line (Mountain Master) Reyco, Tuthill IFS Model 1460	2005 - 2006	Spartan		41-230	S-1460K4
	M-Line (Moutain Master) Reyco, Granning, Tuthill IFS Model 1660	2013 - 2014	Spartan		41-230	S-1460K4
	M-Line (Mountain Master) Reyco, Tuthill Granning IFS Model 1700	2014	Spartan		41-230	S-1460K4
	M-Line (Mountain Master) Reyco, Granning 1200 Straight I-beam Axle	2005	Spartan		41-230	S-124K3
	M-Line (Mountaiin Master) Hendrickson - AirTec	2011 - 2014	Spartan	Hendrickson AirTec	41-230	55-194-6 / 55-208 / 1750K
	N-Line (IC Intermediate)		Spartan		41-230	S-112K3
	N-Line American Eagle Eaton Axle (with 1 3/4" Tie Rod)	1991	Spartan		41-230	S-112K3
	P-Line (EC-2000) Westport Axle Mfg. After 3/1993	1993	Spartan		41-230	G-002K1
	P-Line (EC-2000) (Winn-Vectra & Pusher)	1993	Spartan		41-230	G-002K1
	P-Line (EC-2000)	1992 & Prior	Spartan		41-230	S-EC2K
	P-Line Dutchstar (Air Bags Diesel)	1994	Spartan		41-230	G-002K1
	P-Line Dutchstar W/O Air Bags Diesel (with 1 3/4" Tie Rod)	1994	Spartan		41-230	S-112K3



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	P-Line EC-2000	1995	Spartan		41-230	V-917K1
	Pusher	1991 & Prior	Spartan		41-230	S-138K2
	Pusher Mfg. Before (3/1993) 1992-1993 & Highlander 4Th Didget C	1992 - 1993	Spartan		41-230	S-112K3
	R-Line (EC-1000)(KC-1000)		Spartan		41-230	S-EC2K
	Summit	1998 & Prior	Spartan		41-230	S-181K1
	Summit ES Chassis Rexall American Clipper	2002	Spartan		41-230	G-002K3
	Summit Independent Front Suspension		Spartan			N/A
	Summit Straight Axle (with 1 1/2" Tie Rod)	1999 - 2001	Spartan		41-230	S-103K2
	Summit Straight Axle (with 1 3/4" Tie Rod)	1999 - 2001	Spartan		41-230	S-103K3
	Summit Straight Axle (with 2" Tie Rod)	1999 - 2001	Spartan		41-230	S-181K4
	TB Line Cableless Eurotrans Xlt (with 1 3/4" Tie Rod)		Spartan		41-230	G-002K3
	Motorhome Chassis W/ IPD Sway Bar		Spartan	MM I-Beam	41-230	S-124K3
<b>Special</b>						
<b>Application: Spartan</b>	<b>Granning Independent Front Suspension ( I F S ) Model 1050</b>				<b>42-230</b>	<b>S-IFSK2 *</b>
<b>Note:Spartan</b>	1999 - 2009 The 4Th Didget Of The Vin# Determines The Model Line B = M Line (Mountain Master)					
<b>Note: Spartan</b>	C = Alpine D = Summit					
<b>Note:Spartan</b>	1995 - 1998 The 4Th Didget Of The Vin# Determines The Model Line B = M Line (Mountain Master)					
	D = Alpine 4 = Summit					
<b>Sport Coach</b>	<b>Cross Country</b>	<b>2006 - 2008</b>	<b>Freightliner</b>	<b>XC</b>	<b>41-230</b>	<b>F-143K2</b>
	Cross Country SE	2002 - 2006	Freightliner	XC	41-230	F-143K2
	Elite	2002 - 2008	Freightliner	XC	41-230	F-143K2
	Encore	2006-2007	Freightliner	XC	41-230	F-143K2
<b>Sport Coach</b>	<b>Legend (Independent Front Suspension) ZF Model</b>	<b>2007</b>	<b>Freightliner</b>	<b>XC - IFS</b>		<b>N/A</b>
	Pathfinder	2008	Freightliner	XC	41-230	F-143K2
	Sport Coach	2002 - 2005	Freightliner	XC	41-230	F-143K2
<b>Suzuki</b>	<b>Sidekick (4x2 &amp; 4x4)</b>	<b>1990 - 1999</b>			<b>30-070</b>	<b>G-303K</b>
<b>Thomas</b>	<b>1-1/2" Tie Rod</b>				<b>41-230</b>	<b>G-002K2</b>
	1-3/4" Tie Rod				41-230	G-002K3
	2" Tie Rod				41-230	G-002K4
	Freightliner F60	2004	Freightliner	F-60	41-230	R-104K3
	Measure Tie Rod					
<b>Thor</b>	<b>A.C.E. Evo ( with 19.5 inch wheels)</b>		<b>Ford</b>	<b>F-53</b>	<b>SEE FORD CHASSIS</b>	<b>SEE FORD CHASSIS</b>
	ACE (with 19.5" wheels)	2010 - 2016	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS





# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Astoria	2005 -2012	Freightliner	XC	41-230	F-143K2
	Avanti (note: Modified 130 bkt notch for shock mount)	2009 - 2011	Freightliner	MCL	41-180	55-130-5 / 55-206 / 1375K
	Axis (24.1, 24.2, 25.1, 25.2, 25.3)		Ford	E-350	31-140	E-353K14
	Axis (24.1, 24.2, 25.1, 25.2, 25.3)		Ford	E-450	31-140	E-353K14
	E-Z Rider Transport Bus				41-230	V-814K4
	Challenger2013 F-66 22.5" wheels		Ford		41-180	F-53K2.5
	Four Winds	2015	Ford	E-450	31-140	E-353K14
	Freedom Elite	2012 - 2014	Chevrolet	3500 Cutaway Express	31-140	C-354K14
	Hurricane (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Miramar	2016	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Palazzo		Freightliner	XCS	41-230	F-143K3
	Serano	2009 - 2011	Workhorse	DSL	41-230	W-104K1.5
	Tuscany	2005 - 2015	Freightliner	XC	41-230	F-143K2
	Vegas (RUV) (V10)	2014 - 2016	Ford	E-350	31-140	E-353K14
<b>Tiffin</b>	<b>Allegro</b>	<b>2005 - 2011</b>	<b>Workhorse</b>	<b>W20/22</b>	<b>41-230</b>	<b>W-104K1.5</b>
	Allegro (with 19.5 inch wheels)	2005 -2011	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Allegro	2007 - 2011	Freightliner	MC-FRED	41-230	H-190K2.5
	Allegro 40		Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Allegro 42		Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Allegro Bay (with 19.5 inch wheels)	2005 -2008	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Allegro Bay	2005 - 2010	Workhorse	W20/24	41-230	W-104K1.5
	Allegro Bay	2006 - 2010	Freightliner	MC-FRED	41-230	H-190K2.5
	Allegro Breeze		Tiffin	Power Glide I-Beam	41-230	T-195K2.5
	Allegro Breeze (IFS - Reyco Granning 1000; Last 6 VIN digits 115811 or less)	2013 - 2016	Tiffin	PowerGlide	41-230	Call 1-800-872-7233
	Allegro Breeze (IFS - Reyco Granning 1000; Last 6 VIN digits 115812 or higher)	2013 - 2016	Tiffin	PowerGlide	26-230	Call 1-800-872-7233
	Allegro Bus (1998)		Freightliner	XC		NO FIT
	Allegro Bus	2002 - 2006	Freightliner	XC	41-230	F-143K2
	Allegro Bus (Independent Front Suspension) ZF Model	2005 - 2010	Freightliner	XC - IFS		NO FIT
	Allegro Bus	2008 - 2010	Powerglide	MMGT Tuthill 1460	41-230	S-1460K4
	Allegro Bus (Power Glide with IFS ZF)	2010 - 2013	Powerglide	IFS - ZF		NO FIT
<b>Tiffin</b>	<b>Allegro Red</b>		<b>Freightliner</b>		<b>41-230</b>	<b>F-143K2.5</b>
	Phaeton	2002 - 2009	Freightliner	XC	41-230	F-143K3
	Phaeton (with Power Glide with I-beam) (Spicer)	2011	Powerglide		41-230	G-002K4
	Phaeton 42 w/tag		Spartan	MM I-Beam	41-230	S-124K3
	Phaeton 42 w/tag	2011 - 2014	Spartan	Hendrickson AirTec	41-230	55-194-6 / 55-208 / 1750K
	Zephyr (Reyco Granning 1700)	2013	Spartan	IFS	41-230	S-1460K4
	Zephyr 2002 (Independent Front Suspension) Neway 114	2002	Freightliner	Powerliner IFS	42-230	F-IFSK2 or K2SG *
	Zephyr 45 w/tag	2008 - 2012	Spartan	K2 Tuthill 1660	41-230	S-1460K4
<b>Toyota</b>	<b>1-Ton V-6</b>	<b>1990 - 1991</b>			<b>31-140</b>	<b>T-327K</b>
	Landcruiser	1998			31-140	A-314K13
	Landcruiser LXL	2002			31-140	A-313K13
	Landcruiser VXR	2002			31-140	T-401K13
<b>Travel Supreme</b>	<b>Alante 45</b>	<b>2008</b>	<b>Spartan</b>	<b>K2 Tuthill 1460</b>	<b>41-230</b>	<b>S-1460K4</b>

# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE-T PLUS	Mounting Hardware Kit
	Envoy 40	2008	Spartan	MMGT Tuthill 1260	41-230	S-1460K4
	Envoy 42 w/tag	2008	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Insignia 40	2008	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Insignia 42/45 w/tag	2008	Spartan	MMGT Tuthill 1460	41-230	S-1460K4
	Mid Engine 41		Spartan	MMME Tuthill 1460	41-230	S-1460K4
	Select		Spartan	K2 Tuthill 1660	41-230	S-1460K4
	Select Limited 45		Spartan	K3 Dana IFS 84		N/A
<b>Triple E</b>	<b>Commander (with 19.5 inch wheels)</b>	<b>2001 - 2008</b>	<b>Ford</b>	<b>F-53</b>	<b>SEE FORD CHASSIS</b>	<b>SEE FORD CHASSIS</b>
	Commander	2003 - 2008	Workhorse	W22/24	41-230	W-104K1.5
	Commander	2008 - 2010	Freightliner	MC-FRED	41-230	H-190K2.5
	Embassy	2001 - 2002	Workhorse	W22/24	41-230	W-104K1.5
	Embassy (with 19.5 inch wheels)	2001 - 2004	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Embassy	2004 - 2006	Freightliner	XC	41-230	F-143K2
	Embassy (with 19.5 inch wheels)	2007 - 2008	Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Empress	2001 - 2003	Freightliner	XC	41-230	F-143K2
	Empress (Independent Front Suspension) Neway 114	2002 - 2003	Freightliner	XC - IFS	42-230	F-IFSK2 or K2SG *
	Empress	2004 - 2005	Freightliner	XC	41-230	F-143K2
	Empress (Independent Front Suspension) ZF Model	2004 - 2010	Freightliner	XC - IFS		N/A
	Invitation	2007 - 2010	Freightliner	XC	41-230	F-143K2
	Signature	2002 - 2010	Freightliner	XC	41-230	F-143K2
<b>Vogue</b>	<b>Prima Vista (with Airbags)</b>		<b>Crown</b>		<b>41-230</b>	<b>V-917K2</b>
	Prima Vista	1994 - 1999	Crown		41-230	G-002K2
	Prima Vista (with Independent Front Suspension)		Crown		N/A	N/A
<b>Western RV</b>	<b>Alpine (with 1 3/4" Tie Rod)</b>	<b>2000 - 2005</b>	<b>Peak</b>		<b>41-230</b>	<b>F-53K3</b>
	Alpine (with 2" Tie Rod)	2000 - 2005	Peak		41-230	F-53K4
<b>Winnebago</b>	<b>Adventurer</b>		<b>Workhorse</b>	<b>W22/24</b>	<b>41-230</b>	<b>W-104K1.5</b>
<b>Winnebago</b>	Adventurer 35A (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Aspect	2010 - 2016	Ford	E-450	31-140	E-353K14
	Chalet		John Deere		41-230	JD-800K1
	Chalet		Chevrolet	P-30	31-140	P-30KB13
	Chalet		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Chieftain (19.5" Wheels) 35 feet or shorter		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Chieftain (22.5" Wheels) 35 feet or shorter		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Chieftain		Chevrolet	P-30 / P-37	31-140	P-30KB13
	Destination	2008 - 2010	Freightliner	XC	41-230	F-143K2
	Destination	2008 - 2010	Workhorse	UFO	41-230	H-190K2.5
	Itasca Passage		Chevrolet	P-30	31-140	P-30KB13
	Journey	2002 - 2010	Freightliner	XC	41-230	F-143K2
	Meridian	2012-2013	Workhorse	w/20/22	41-230	W-104K1.5
	Sightseer		Workhorse	W20/22	41-230	W-104K1.5
	Sightseer (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Tour	2006 - 2010	Freightliner	XC	41-230	F-143K2



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model	SAFE T PLUS	Mounting Hardware Kit
	Ultimate Advantage		Spartan	MM w/1370	26-230	S-115K2.5
	Ultimate Advantage	1999 - 2000	Freightliner	XC - IFS	41-230	
	Ultimate Freedom (Reyco Granning 1200)	2002	Spartan	IFS	26-230	S-115K2.5
	Vectra	2004	Freightliner	XC	41-230	F-143K2
	Vectra Freightliner Evolution	2005	Freightliner	IFS	42-230	F-IFSK2 *
	Vectra (Independent Front Suspension) ZF Model	2004 - 2010	Freightliner	XC - IFS		N/A
	View	2012 - 2014	Mercedes	Sprinter Chassis		N/A
	Vista (with 19.5 inch wheels)		Ford	F-53	SEE FORD CHASSIS	SEE FORD CHASSIS
	Voyage		Workhorse	W22/24	41-230	W-104K1.5
<b>Workhorse</b>	<b>DSL Series Unibody (Serano )</b>	<b>2009 - 2011</b>	<b>Workhorse</b>	<b>DSL</b>	<b>41-230</b>	<b>W-104K1.5</b>
	M Series UFO	2007 - 2008	Workhorse	UFO w/ Steertek	41-230	H-190K2.5
	P-30, P-32, P-37, P-Cutaway & Workhorse P-32		Workhorse		31-140	P-30KB14
	P-32 (Gvw 18,000 Lbs.)	1999 - 2005	Workhorse		31-140	P-30KB13
	P-42 Dynamax Corp Isata Touring Sedan Class A		Workhorse		31-140	W-352K12
	R Series Straight Axle With Airbags Deisel Pusher	2004 - 2005	Workhorse		41-230	G-002K3
	R Series	2006 - 2008	Workhorse		41-230	S-124K3.5
	W16/18/20/22/24 (Straight Axle) <b>with out</b> shock & shock mounts	Through current	Workhorse	W16/18/20/22/24	41-230	W-104K1.5
	W16/18/20/22/24 (Straight Axle) <b>WITH</b> shock & shock mounts	Through current	Workhorse	W16/18/20/22/24	41-230	W-104K1.5
	W-42 (with 1 5/16 tie rod)	2006	Workhorse	W-42	41-140	W-042K1.5

**Special**

<b>Application: Spartan</b>	Granning Independent Front Suspension ( I F S ) Model 1050				42-230	<b>S-IFSK2 *</b>
-----------------------------	--	--	--	--	--------	------------------

**Note:**

1999 - 2009 The 4Th Didget Of The Vin# Determines The Model Line
B = M Line (Mountain Master)
C = Alpine
D = Summit
1995 - 1998 The 4Th Didget Of The Vin# Determines The Model Line
B = M Line (Mountain Master)
D = Alpine
4 = Summit

**Special**

<b>Application: Freightliner</b>	Neway I.F.S. 2003-2005 No Fit	2003 - 2005			42-230	<b>F-IFSK2 or K2SG *</b>
----------------------------------	-------------------------------	-------------	--	--	--------	--------------------------

**Note: Oshkosh**

The 12Th Digit Of Vin#
1 - 299999 = M Line
300000 - 499999 = X Line
500000 - 502999 = L Line
900000 - 999999 = V Line

← SAME DAY SHIPPING OF YOUR ORDER →

**Need Help Finding Which Safe-T-Plus Unit and Mounting Kit You Need?**  
 Contact Us at [support@safe-t-plus.com](mailto:support@safe-t-plus.com)  
 or (800) 872-7233



# 2016 Motorhome Fit Guide

Lifetime Vehicle Warranty • 1 Hour Bolt-on install • Easy to Center • No Welding • No drilling • Maintenance free

RV / Chassis Make	Coach / Chassis Model	Year	Chassis Type	Chassis Model		Mounting Hardware Kit
-------------------	-----------------------	------	--------------	---------------	---	-----------------------

 SAME DAY SHIPPING OF YOUR ORDER 

 **Need Help Finding Which Safe-T-Plus Unit and Mounting Kit You Need?**  
Contact Us at [support@safe-t-plus.com](mailto:support@safe-t-plus.com)  
or (800) 872-7233